

The plot of inhibitor concentration over degree of surface coverage versus inhibitor concentration gives a straight line as shown in Fig. 5. The strong correlation reveals that egg shell adsorption on stainless surface in 0.5 M H₂SO₄ follow Langmuir adsorption isotherm. Figs. 6–8 show the SEM/EDX surface morphology analysis of stainless steel. Figs. 7 and 8 are the SEM/EDX images of the stainless steel specimens without and with inhibitor after weight loss experiment in sulphuric acid medium. The stainless steel surface corrosion product layer in the absence of inhibitor was porous and as a result gives no corrosion protection. With the presence of ES, corrosion damage was minimized, with an evidence of ES present on the metal surface as shown in Fig. 8.

Table 1

Potentiodynamic polarization data for stainless steel in the absence and presence of ES in 0.5 M H₂SO₄ solution.

Inhibitor
concentration (g)
bc (V/dec)
ba (V/dec)
E _{corr} (V)
i _{corr} (A/cm ²)
Polarization
resistance (Ω)

Corrosion

rate (mm/year)

0

0.0335

0.0409

0.9393

0.0003

24.0910

2.8163

2

1.9460

0.0596

0.8276

0.0002

121.440

1.5054

4

0.0163

0.2369

0.8825

0.0001

42.121

0.9476

6

0.3233

0.0540

0.8027
5.39E-05
373.180
0.4318
8
0.1240
0.0556
0.5896
5.46E-05
305.650
0.3772
10
0.0382
0.0086
0.5356
1.24E-05
246.080
0.0919

Fig. 4. Anodic and cathodic polarization curve of stainless steel in 0.5 M H₂SO₄ solution in the presence and absence of ES.

10
8
6
4
2
2

4

6

8

10

12

C/0

Concentration (g)

C/0

Fig. 5. Langmuir adsorption isotherm of ES.

O. Sanni, A.P.I. Popoola / Data in Brief 22 (2019) 451–457

454

